Service Kit

Priming Tank Ball Float

Revision 1

Date: 16 Oct 2025

Access to PartsBender website

Contents

Exploded View 1
Service Kits 2

Priming Tank Ball Float Assembly

Access to PartsBender website

Service Kits

Kit P/N: ASM-G5C36-0002
Kit Description: Assembly Priming Linkage GEN3 Ball Assembly SS304 to suit Pioneer Pump

Item	Material	Qty
LINKAGE SHIM A	304 SS	1
LINKAGE SHIM B	304 SS	1
LINKAGE SHIM C	304 SS	1
LINKAGE PIN B	304 SS	2
LINKAGE HOUSING	304 SS	1
LINKAGE CONNECTOR A	304 SS	1
LINKAGE CONNECTOR B	304 SS	1
LINKAGE PIN A	304 SS	2
LOCK NUT 3/16”-24	304 SS	4
SPACER WASHER	304 SS	4
LINKAGE ARM UPPER	304 SS	1
LINKAGE ARM LOWER	304 SS	1
LINKAGE ARM BRACKET	304 SS	1
SPRING WASHER	304 SS	2
BOLT HEX 3/8” -16 UNC	304 SS	2
BOLT HEX 5/16”-18 UNC	304 SS	1
FLOAT BALL	304 SS	1
LOCK NUT 5/16”-18	304 SS	1



Kit P/N: KIT-G5C36-0001
Kit Description: KIT Lid Priming Ball Float Assembly SS304 to suit Pioneer Pump

Item	Material	Qty
SQUARE HEAD PLUG 1/2“	304 SS	1
PRIMING CHAMBER LID	304 SS	1
PRIMING CHAMBER LID GASKET	VITON	1



Access to PartsBender website

Kit P/N: ASM-G5C36-0003
Kit Description: Assembly Priming Valve Spring Assembly SS304 to suit Pioneer Pump

Item	Material	Qty
LOCK NUT 1/4”-20	304 SS	2
WASHER VALVE	304 SS	1
VALVE SEAT	304 SS	1
SOCKET HEAD SCREW 3/8”-16	304 SS	2
VALVE COVER	304 SS	1
O-RING SMALL	VITON	1
FLAT WASHER	304 SS	3
O-RING LARGE	VITON	1
VALVE STEM	304 SS	1
SPRING	304 SS	1
FENDER WASHER	304 SS	1